



Item No.	Name of Part	Item No.	Name of Part	Item No.	Name of Part
1	Casing	*49	Bearing Cover Seal (Outboard)	236	Pipe Plug
2	Impeller	66	Shaft Adjusting Unit	239	Cap Screws
6	Pump Shaft	*73	Casing Gasket	240	Pipe Plug
9	Suction Cover	127	Tubing Assembly with Connectors	*241	Stuffing Box Gasket
11	Packing Box Cover			242	Grease Fitting
*13	Packing	203	Name Plate	243	Grease Fitting
*16	Ball Bearing (Inboard)	204	Adjusting Lock Nut	257	Clamping Ring
17	Split Gland	207	Grease Fitting		
*18	Ball Bearing (Outboard)	208	Pipe Plug	*269	Cotter Pin
19	Frame	209	Cap Screw, Machine Bolt, or Stud	270	Impeller Washer
24	Impeller Nut	210	Hex Nut		
*29	Lantern Ring	213	Cap Screw	*303	Bearing Cover Gasket
32	Impeller Key	214	Drive Screw	337	Cap Screw
37	Bearing Cover (Outboard)	215	Cap Screws	347	Spring
40	Deflector	216	Pipe Plug	352	Pipe Plug
46	Coupling Key	229	Lockwasher		

\* Recommended spare parts